

Technical Description

**ENERCON Wind Energy Converter
E-141 EP4**

Publisher

ENERCON GmbH ▪ Dreekamp 5 ▪ 26605 Aurich ▪ Germany
Phone: +49 4941 927-0 ▪ Fax: +49 4941 927-109
E-mail: info@enercon.de ▪ Internet: <http://www.enercon.de>
Managing Directors: Hans-Dieter Kettwig, Simon-Hermann Wobben
Local court: Aurich ▪ Company registration number: HRB 411
VAT ID no.: DE 181 977 360

Copyright notice

The entire content of this document is protected by copyright and – with regard to other intellectual property rights – international laws and treaties. ENERCON GmbH holds the rights in the content of this document unless another rights holder is expressly identified or obviously recognisable.

ENERCON GmbH grants the user the right to make copies and duplicates of this document for informational purposes for its own intra-corporate use; making this document available does not grant the user any further right of use. Any other duplication, modification, dissemination, publication, circulation, surrender to third parties and/or utilisation of the contents of this document – also in part – shall require the express prior written consent of ENERCON GmbH unless any of the above is permitted by mandatory legislation.

The user is prohibited from registering any industrial property rights in the know-how reproduced in this document, or for parts thereof.

If and to the extent that ENERCON GmbH does not hold the rights in the content of this document, the user shall adhere to the relevant rights holder's terms of use.

Registered trademarks

Any trademarks mentioned in this document are intellectual property of the respective registered trademark holders; the stipulations of the applicable trademark law are valid without restriction.

Reservation of right of modification

ENERCON GmbH reserves the right to change, improve and expand this document and the subject matter described herein at any time without prior notice, unless contractual agreements or legal requirements provide otherwise.

Document details

Document ID	D0438356-2		
Note	Original document. Source document of this translation: D0437728-2/2016-08-29		
Date	Language	DCC	Plant/department
2016-12-08	en	DA	WRD Management Support GmbH / Documentation Department

Table of contents

1	Overview of ENERCON E-141 EP4	1
2	ENERCON wind energy converter concept.....	2
3	E-141 EP4 components.....	3
3.1	Nacelle.....	3
3.2	Rotor blades	4
3.3	Tower.....	4
4	Grid Management System	6
5	Safety system	9
5.1	Safety equipment.....	9
5.2	Sensor system	9
6	Control system.....	12
6.1	Yaw system	12
6.2	Pitch control	12
6.3	WEC start	13
6.3.1	Start lead-up.....	13
6.3.2	Wind measurement and nacelle alignment	13
6.3.3	Generator excitation	14
6.3.4	Power feed	14
6.4	Operating modes	15
6.4.1	Full load operation.....	15
6.4.2	Partial load operation	16
6.4.3	Idle mode.....	16
6.5	Safe stopping of the wind energy converter	17
7	Remote monitoring	18
8	Maintenance	19
	Technical Specifications E-141 EP4.....	20

1 Overview of ENERCON E-141 EP4

The ENERCON E-141 EP4 wind energy converter is a direct-drive wind energy converter with a three-bladed rotor, active pitch control, variable speed operation, and a nominal power output of 4200 kW. It has a rotor diameter of 141 m and can be supplied with hub heights of 129 m and 159 m.



Fig. 1: Complete view of ENERCON E-141 EP4

2 ENERCON wind energy converter concept

Gearless

The E-141 EP4 drive system comprises very few rotating components. The rotor hub and the rotor of the annular generator are directly interconnected to form one solid unit. This reduces the mechanical strain and increases technical service life. Maintenance and service costs are reduced (fewer wearing parts, no gear oil change, etc.) and operating expenses are also minimised. Since there are no gears or other fast rotating parts, the energy loss between generator and rotor as well as noise emissions are considerably reduced.

Active pitch control

Each of the 3 rotor blades is equipped with a pitch unit. Each pitch unit consists of an electrical drive, a control system, and a dedicated emergency power supply. The pitch control drive for each rotor blade consists of 4 direct-current compositely excited motors with installed gear. The pitch units limit the rotor speed and the amount of power extracted from the wind. This way, the maximum output of the E-141 EP4 can be accurately limited to nominal power, even at short notice. By pitching the rotor blades into the feathered position, the rotor is stopped without any strain on the drive train caused by the application of a mechanical brake.

Indirect grid connection

The power produced by the annular generator is fed into the distribution or transport grid via the ENERCON grid management system. The ENERCON grid management system, which consists of a rectifier, a DC link and a modular inverter system, ensures maximum energy yield with excellent power quality. The electrical properties of the annular generator are therefore irrelevant to the behaviour of the wind energy converter in the distribution or transport grid. Rotational speed, excitation, output voltage and output frequency of the annular generator may vary depending on the wind speed. In this way, the energy contained in the wind can be optimally exploited even in the partial load range.

3 E-141 EP4 components




Fig. 2: View of E-141 EP4 nacelle

1 Slip ring unit	2 Hub
3 Hub adapter	4 Blade adapter
5 Generator rotor	6 Generator stator
7 Stator support	8 Beacon system (optional)
9 Generator stator water cooling system chiller	10 Wind measuring unit with lightning rods
11 Winch	12 Yaw drives
13 Main carrier	14 Nacelle casing

3.1 Nacelle

The hub rotates on the fixed axle pin on 2 hub bearings. Among other components, the rotor blades and the generator rotor are attached to the hub. The generator stator is carried by the stator support with 6 stator jibs. The slip ring unit is located at the tip of the axle pin. It transmits electrical energy and data between the stationary and the rotating parts of the nacelle via sliding contacts.

The support pin connects the stator support to the main carrier. Mounted on the ends of the jibs is the two-part stator ring that holds the copper windings in which the electric current is induced.

Together with the yaw carrier connected to it, the main carrier is the central load-bearing element of the nacelle structure. All rotor and generator components are attached to it either directly or indirectly. The yaw carrier rotates on the tower head by means of the yaw bearing. The entire nacelle can be rotated by the yaw drives, so that the rotor is always optimally aligned with the wind.

The nacelle casing is made of aluminium. It consists of multiple sections that attach to the generator stator, the frame (in the machine house) and the hub (in the rotor area) via extruded profiles.

3.2 Rotor blades

The segmented rotor blades made of glass-fibre reinforced plastic (GRP; glass fibre and epoxy resin), balsa wood and foam have a major influence on the wind energy converter's yield and its noise emission. The inner rotor blade is a solid GRP component and is manufactured using the filament winding technique. The outer rotor blade is manufactured using half shells and the vacuum infusion method.

The shape and profile of the E-141 EP4 rotor blades were designed with the following criteria in mind:

- High power coefficient
- Long service life
- Low noise emission
- Low mechanical strain
- Efficient use of material

One special feature to be pointed out is the rotor blade profile, which extends down to the nacelle. This design prevents the loss of the inner air flow experienced with conventional rotor blades. In combination with the streamlined nacelle, utilisation of the wind supply is considerably optimised.

The rotor blades of the E-141 EP4 were specially designed to operate with variable pitch control and at variable speeds. The polyurethane-based surface coating protects the rotor blades from environmental impacts such as UV radiation and erosion. This coating is highly resistant to abrasion.

Microprocessor-controlled pitch units that are independent of one another adjust each of the 3 rotor blades. 2 angle encoders in each rotor blade constantly monitor the set blade angle and ensure blade angle synchronisation across all 3 blades. This provides for quick, precise adjustment of blade angles according to the prevailing wind conditions.

3.3 Tower

The tower of the E-141 EP4 wind energy converter is a hybrid tower assembled from precast concrete segments and a steel section. For technical and economic reasons, the slender top part of the E-141 EP4 hybrid tower is made of steel. It is not possible, for example, to install the yaw bearing directly on the concrete elements and the considerably thinner wall of the steel section provides for more space in the tower interior.

The tower is painted and equipped with weather and corrosion protection at the factory. This means that no work is required in this regard after assembly except for repairing any defects or transport damage. By default, the paintwork on the bottom of the tower has a graded colour scheme (can be omitted if desired).

The hybrid tower is assembled from the precast concrete elements at the installation site. As a rule, segments are dry-stacked; however, a compensatory grout layer can be applied. Vertical joints are bolted. As a final step, the top steel section is placed on the tower and bolted.

Towers are prestressed vertically by means of prestressing steel tendons. The prestressing tendons run vertically either through ducts in the concrete elements or externally along the interior tower wall. They are anchored to the foundation.

4 Grid Management System

Annular generator and energy flow

The E-141 EP4 is equipped with a multi-polar, separately excited asymmetrical synchronous generator (annular generator). The wind energy converter operates at variable speeds in order to fully exploit the wind energy potential at all wind speeds. The magnetic field generated by the excitation current in the generator rotor induces an alternating current with varying voltage, frequency and amplitude in the generator stator.

The generator stator consists of 2 separate stator sections. The windings in each stator section form four 3-phase alternating current systems that are independent of each other. These 8 alternating current systems are each independently rectified in the nacelle and are reduced to 4 DC voltage systems by merging the connection at the rectifier outputs. The DC voltage systems are connected to the 4 DC busbars in the E-module via the tower cables. Up to 5 power cabinets can be connected to one DC busbar system. After having been converted to three-phase current whose voltage, frequency and phase position conform to the grid, the outputs of the power cabinets are merged to 2 AC busbar systems and are then adjusted to the voltage level (e.g. 20 kV) of the utility company's grid by one medium-voltage transformer each. Consequently, the annular generator is not directly connected to the receiving power grid of the utility company; instead, it is completely decoupled from the grid by the ENERCON grid feed system.




Fig. 3: Simplified electric diagram of an ENERCON wind energy converter

Decoupling the annular generator from the grid provides for optimum power transmission. Sudden changes in wind speed are translated into controlled change in fed-in power on the grid side. Conversely, possible grid faults have virtually no effect on the mechanics of the wind energy converter. The power injected by the E-141 EP4 can be precisely regulated from 0 kW to 4200 kW.

In general, the features required for a specific wind energy converter or wind farm to be connected to the receiving power grid are predefined by the operator of that grid. To meet different requirements, ENERCON wind energy converters are available with different configurations.

The inverter system in the tower base is dimensioned according to the particular configuration of the wind energy converter. As a rule, a transformer inside or near the wind energy converter converts 400 V low voltage to the desired medium voltage.

FACTS

If necessary, an E-141 EP4 equipped with standard FACTS (Flexible AC Transmission System) control can supply reactive power in order to contribute to reactive power balance and to maintaining voltage levels in the grid. The maximum reactive power range is available at an output as low as 10 % of the nominal active power. The maximum reactive power range varies, depending on the configuration of the wind energy converter.

FT configuration

FACTS Transmission (FRT)

By default, the E-141 EP4 comes equipped with FACTS technology that meets the stringent requirements of specific grid codes. It is able to ride through grid faults (under-voltage, overvoltage, automatic reclosing, etc.) of up to 5 seconds (FT = FACTS + FRT [Fault Ride Through]) and to remain connected to the grid during these faults.

If the voltage measured at the reference point exceeds a defined limit value, the ENERCON wind energy converter changes from normal operation to a specific fault operating mode.

Once the fault has been cleared, the wind energy converter returns to normal operation and feeds the available power into the grid. If the voltage does not return to the operating range admissible for normal operation within an adjustable time frame (5 seconds max.), the wind energy converter is disconnected from the grid.

While the system is riding through a grid fault, various fault modes using different grid feed strategies are available, including feeding in additional reactive current in the event of a fault. The control strategies include different options for setting fault types.

Selection of a suitable control strategy depends on specific grid code and project requirements that must be confirmed by the particular grid operator.

FTS configuration

FACTS Transmission (FRT) with STATCOM option

Same as FT configuration; however, the STATCOM (**Static Compensator**) option additionally enables the wind energy converter to output and absorb reactive power regardless of whether it generates and feeds active power into the grid. It is thus able to actively support the power grid at any time, similar to a power plant. STATCOM includes a special electrical cabinet that is typically installed close to the transformer. Whether or not this configuration can be used needs to be determined on a project-specific basis.

FTQ configuration**FACTS Transmission (FRT) with Q+ option**

The FTQ configuration comprises all features of the FT configuration. In addition, it has an extended reactive power range.

FTQS configuration**FACTS Transmission (FRT) with Q+ and STATCOM options**

The FTQS configuration comprises all features of the FTQ and FTS configurations.

Frequency protection

ENERCON wind energy converters can be used in grids with a nominal frequency of 50 Hz or 60 Hz.

The range of operation of the E-141 EP4 is defined by a lower and upper frequency limit value. Overfrequency and underfrequency events at the reference point of the wind energy converter trigger frequency protection and cause the wind energy converter to shut down after the maximum delay time of 60 seconds has elapsed.

Power-frequency control

If temporary overfrequency occurs as a result of a grid fault, ENERCON wind energy converters can reduce their power feed dynamically to contribute to restoring the balance between the generating and transmission networks.

As a pre-emptive measure, the active power feed of ENERCON wind energy converters can be limited during normal operation. During an underfrequency event, the power reserved by this limitation is made available to stabilise the frequency. The characteristics of this control system can be easily adapted to different specifications.

5 Safety system

The E-141 EP4 comes with a large number of safety features whose purpose is to permanently keep the wind energy converter inside a safe operating range. In addition to components that ensure safe stopping of the wind energy converter, these include a complex sensor system. It continuously captures all relevant operating states of the wind energy converter and makes the relevant information available through the ENERCON SCADA remote monitoring system.

If any safety-relevant operating parameters are out of the permitted range, the wind energy converter continues running at limited power, or is stopped.

5.1 Safety equipment

Emergency stop button

In an ENERCON wind energy converter there are emergency stop buttons next to the tower door, on the control cabinet in the tower base, on the nacelle control cabinet and, if required, on further levels of the E-module. Actuating an emergency stop button at the tower base activates emergency pitching of the rotor blades. This brakes the rotor aerodynamically. Actuating an emergency stop button in the nacelle activates the rotor brake in addition to emergency pitching. This stops the rotor as quickly as possible.

The following are still supplied with power:

- Rotor brake
- Beacon system components
- Lighting
- Sockets

Main switch

In an ENERCON wind energy converter, main switches are installed on the control cabinet and the nacelle control cabinet. When actuated, they de-energise virtually the entire wind energy converter.

The following are still supplied with power:

- Beacon system components
- Service hoist
- Sockets
- Lighting
- Medium-voltage area

5.2 Sensor system

A large number of sensors continuously monitor the current status of the wind energy converter and the relevant ambient parameters (e.g. rotor speed, temperature, blade load, etc.). The control system analyses the signals and regulates the wind energy converter such that the wind energy available at any given time is always optimally exploited and at the same time operating safety is ensured.

Redundant sensors

To be able to check plausibility by comparing the reported values, more sensors than necessary are installed for some operating states. This applies to temperature measurement in the generator, wind speed measurement or measuring the current rotor blade angle. Defective sensors are reliably detected and can be repaired or replaced by activating spare sensors. This way, the wind energy converter can safely continue its operation without having to replace major components.

Sensor checks

Proper functioning of all sensors is either regularly checked by the WEC control system itself during normal WEC operation or, where this is not possible, in the course of WEC maintenance work.

Speed monitoring

The control system of the ENERCON wind energy converter regulates the rotor speed by adjusting the blade angle such that the speed does not significantly exceed nominal speed even during very high winds. However, pitch control may not be able to react quickly enough to sudden events such as strong gusts of wind or a sudden drop of the generator load. If nominal speed is exceeded by more than 15 %, the control system stops the rotor. After 3 minutes the wind energy converter automatically attempts to restart. If this fault occurs more than five times within a 24 hour period, a defect is assumed. There are no further restart attempts.

In addition to the electronic monitoring system there are 3 electromechanical overspeed switches in the rotor head. They are spaced evenly along the circumference of the rotor. Each of these switches can stop the wind energy converter by means of emergency pitching. The switches respond if the rotor speed exceeds the nominal speed by more than 25 %. To enable the wind energy converter to restart, the overspeed switches must be re-set manually after the cause of the overspeed has been identified and eliminated.

Air gap monitoring

Microswitches distributed along the rotor circumference monitor the width of the air gap between the rotor and the stator of the annular generator. If any of the switches are triggered because the distance has dropped below the minimum distance, the wind energy converter stops and restarts automatically after a brief delay.

If the fault recurs within 24 hours, the wind energy converter remains stopped until the cause has been eliminated.

Oscillation monitoring

Oscillation monitoring detects excessive oscillation or excursion of the wind energy converter tower top. Sensors detect the acceleration of the nacelle along the direction of the hub axis (longitudinal oscillation) and perpendicular to this axis (transverse oscillation). The control system uses this input to calculate the tower excursion compared to its idle position.

In addition, excessive vibrations and shocks such as those that may occur e.g. in the event of a fault in the rectifier are detected by an integrated oscillation monitoring function. If the oscillations or excursion exceed the permissible limit, the wind energy converter stops. It restarts automatically after a short delay. If non-permissible vibrations are detected or if non-permissible tower oscillations occur repeatedly, the wind energy converter stops and does not make any further restart attempts.

Temperature monitoring

Some components in ENERCON wind energy converters are cooled. For this purpose, temperature sensors continuously measure the temperature of the components of the wind energy converter that need to be protected from excessive heat.

In the event of excessive temperatures, the power output of the wind energy converter is reduced. If necessary, the wind energy converter stops. The wind energy converter cools down and generally restarts automatically as soon as the temperature falls below a pre-defined limit.

Some measuring points are equipped with additional overtemperature switches. These also initiate a stop of the wind energy converter once the temperature exceeds a specific limit, in certain cases without an automatic restart after cooling down.

At low temperatures, some assemblies such as the hazard beacon energy storage and the generator are heated in order to keep them operational.

Nacelle-internal noise monitoring

Sensors located in the rotor head respond to loud knocking sounds such as might be caused by loose or defective components. If any of these sensors detect noise and there is nothing to indicate a different cause, the wind energy converter stops.

In order to rule out exterior causes for the noise (mainly the impact of hail during a thunderstorm), the signals from all wind energy converters in a wind farm are matched against each other. For stand-alone WECs, an additional noise sensor in the machine house is used. If the sensors in multiple WECs or the noise sensor in the machine house detect noise simultaneously, an exterior cause is assumed. The noise sensors are deactivated briefly so that none of the wind energy converters in the wind farm stop.

Cable twist monitoring

If the nacelle of the wind energy converter has turned around its own axis more than three times and twisted the cables running down inside the tower, the WEC control system uses the next opportunity to automatically untwist the cables.

The cable twist monitoring feature is equipped with sensors which cut the power supply to the yaw motors if the permitted control range is exceeded.

6 Control system

The E-141 EP4 control system is based on a microprocessor system developed by ENERCON and uses sensors to query all WEC components and collect data such as wind direction and wind speed. Using this information, it adjusts the operating mode of the E-141 EP4 accordingly. The WEC display of the control cabinet in the tower base shows the current status of the wind energy converter and any fault that may have occurred.

6.1 Yaw system

The yaw bearing with an externally geared rim is mounted on top of the tower. The yaw bearing allows the nacelle to rotate, thus providing for yaw control.

If the difference between the wind direction and the rotor axis direction exceeds the maximum permissible value, the yaw drives are activated and adjust the nacelle position according to the wind direction. The yaw motor control system ensures smooth starting and stopping of the yawing motion. The WEC control system monitors the yaw system. If it detects any irregularities it deactivates yaw control and stops the wind energy converter.

6.2 Pitch control

Functional principle

The pitch system modifies the angle of attack, that is the angle at which the air flow meets the blade profile. Changes to the blade angle change the lift at the rotor blade and thus the force with which the rotor blade turns the rotor.

During normal operation (automatic mode) the blade angle is adjusted in a way that ensures optimal exploitation of the energy contained in the wind while avoiding overload of the wind energy converter. Wherever possible, boundary conditions such as noise optimisation are also fulfilled in the process. In addition, blade angle adjustment is used to decelerate the rotor aerodynamically.

If the wind energy converter achieves nominal power output and the wind speed continues to increase, the pitch system turns the rotor blades just far enough out of the wind to keep the rotor speed and the amount of energy extracted from the wind and to be converted by the generator, within or just slightly above the nominal limits.

Installation

Each rotor blade is fitted with a pitch unit. The pitch unit consists of a pitch control box, a blade relay box, the pitch drive and two capacitor units. The pitch control box and the blade relay box control the pitch drive. The capacitor units store the energy required for emergency pitching; during WEC operation, it is kept charged and is continually tested. The pitch control drive for each rotor blade consists of 4 direct-current compositely excited motors with installed gear. These motors are implemented as braking motors.

Blade angle

Special rotor blade positions (blade angles) of the E-141 EP4:

- A: 1° Normal position during partial load operation: maximum exploitation of available wind.
- B: 60° Idle mode (wind energy converter does not feed any power into the grid because the wind speed is too low): Depending on the wind speed, the rotor spins at low speed or stands still (if there is no wind at all).
- C: 92° Feathered position (rotor has been stopped manually or automatically): The rotor blades do not generate any lift even in the presence of wind; the rotor stands still or moves very slowly.




Fig. 4: Special blade positions

6.3 WEC start

6.3.1 Start lead-up

As long as the main status is > 0 , the wind energy converter remains stopped. As soon as the main status changes to 0, the wind energy converter is ready and the start-up procedure is initiated. If certain boundary conditions for start-up, e.g. charging of the capacitor units of the emergency pitching capacitor units, have not yet been fulfilled, status 0 : 3 – Start lead-up is displayed.

During start lead-up, a wind measurement and alignment phase of 150 seconds begins.

6.3.2 Wind measurement and nacelle alignment

After completing start lead-up, status 0 : 2 – Turbine operational is displayed.

If the control system is in automatic mode, the average wind speed is above 1.8 m/s and the wind direction deviation is sufficient for yawing, the wind energy converter starts alignment with the prevailing wind direction. 60 seconds after completing start lead-up the wind energy converter goes into idle mode. The rotor blades are slowly pitched in while a check is performed on the emergency pitching capacitor units.

If the wind energy converter is equipped with load control sensors, the rotor blades stop at an angle of 70° and adjust the load measurement points, which may take several minutes. During this time, status 0:5 – Calibration of load control is displayed.

If the mean wind speed during the wind measurement and alignment phase of 150 seconds is above the current cut-in wind speed (about 2.0 m/s), the start-up procedure is initiated (status 0:1). Otherwise, the wind energy converter remains in idle mode (status 2:1 – Lack of wind : Wind speed too low).

Power consumption

As the wind energy converter is not generating any active power at that moment, the electrical energy consumed by the wind energy converter is taken from the grid.

6.3.3 Generator excitation

Once the rotor reaches a certain rotational speed that depends on the wind turbine type (for instance, approx. 3 rpm for the E-82), generator excitation is initiated. The electricity required for this purpose is temporarily taken from the grid. Once the generator reaches a sufficient speed the wind energy converter supplies itself with power. The electricity for self-excitation is then taken from the DC link; the energy taken from the grid is reduced to zero.

6.3.4 Power feed

As soon as the DC link voltage is sufficient and the excitation controller is no longer connected to the grid, power feed is initiated. After the rotational speed has increased due to sufficient wind and with a power setpoint $P_{\text{set}} > 0$, the line contactors on the low-voltage side are closed and the E-141 EP4 starts feeding power into the grid at approx. 4 rpm.

The number of activated inverters is gradually increased, depending on the number necessary for the power generated by the generator. Power control regulates the excitation current so that power is fed according to the required power curve.

The power increase gradient (dP/dt) after a grid fault or a regular start-up can be defined within a certain range in the control system. For more detailed information, see the *Grid Performance* data sheet for the particular ENERCON wind energy converter type.

6.4 Operating modes

After completion of the E-141 EP4 start-up procedure the wind energy converter switches to automatic mode (normal operation). While in operation, the wind energy converter constantly monitors wind conditions, optimises rotor speed, generator excitation and generator power output, aligns the nacelle position with the wind direction, and records all sensor statuses.

In order to optimise power generation under highly diverse wind conditions when in automatic mode, the wind energy converter changes between 3 operating modes, depending on the wind speed. In certain circumstances the wind energy converter stops if provided for by the configuration of the wind energy converter (e.g. shadow casting). In addition, the utility company into whose grid the generated power is being fed can be given the option to directly intervene in the operation of the wind energy converter by remote control, e.g. for temporary reduction of the power feed.

The E-141 EP4 switches between the following operating modes:

- Full load operation
- Partial load operation
- Idle mode

6.4.1 Full load operation

Wind speed

$v \geq 13 \text{ m/s}$

With wind speeds at and above the rated wind speed, the wind energy converter uses pitch control to maintain rotor speed at the setpoint (approx. 10.6 rpm) and thus limits the power to its nominal value of 4200 kW.

Storm Control enabled (normal case)

Storm control enables WEC operation even at very high wind speeds; however, the rotor speed and the power output are reduced.

If wind speeds exceed approx. 28 m/s (12-second average) and keep increasing, the rotational speed will be reduced linearly from 10.6 rpm to idle speed at about 34 m/s by pitching the rotor blades out of the wind accordingly. The power fed into the grid decreases in accordance with the speed/power curve in the process.

At wind speeds above 34 m/s (10-minute average) the rotor blades are almost in the feathered position. The WEC runs in idle mode and without any power output; it does, however, remain connected to the receiving grid. Once the wind speed falls below 34 m/s, the WEC restarts its power feed.

Storm control is enabled by default and can only be deactivated by remote control or on site by ENERCON Service.

Storm control disabled

If, by way of exception, storm control is disabled, the wind energy converter will be stopped for safety reasons if the wind speed exceeds 25 m/s (3-minute average) or 30 m/s (15-second average). If none of the above events occurs within 10 minutes after stopping, the wind energy converter will be restarted automatically.

6.4.2 Partial load operation

Wind speed

$$2.5 \text{ m/s} \leq v < 13 \text{ m/s}$$

During partial load operation (i.e., the wind speed is between the cut-in wind speed and the rated wind speed) the maximum possible power is extracted from the wind. Rotor speed and power output are determined by the current wind speed. Pitch control already starts as the WEC approaches full load operation so as to achieve a smooth transition.

6.4.3 Idle mode

Wind speed

$$v < 2.5 \text{ m/s}$$

At wind speeds below 2.5 m/s no power can be fed into the grid. The wind energy converter runs in idle mode, i.e., the rotor blades are turned almost completely out of the wind (60° blade angle) and the rotor turns slowly or stops completely if there is no wind at all.

Slow movement (idling) puts less strain on the hub bearings than longer periods of complete standstill; in addition, the WEC can resume power generation and power feed more quickly as soon as the wind picks up.

6.5 Safe stopping of the wind energy converter

The ENERCON wind energy converter can be stopped by manual intervention or automatically by the control system.

The causes are divided into groups by risk.




Fig. 5: Overview of shutdown procedures

Stopping the wind energy converter by means of pitch control

In the event of a fault that is not safety-relevant, the wind energy converter control system pitches the rotor blades out of the wind, causing the rotor blades not to generate any lift and bringing the wind energy converter to a safe stop.

Emergency pitching

The pitch unit's energy storage system provides the energy required for emergency pitching. During operation of the wind energy converter, it is kept charged and continually tested. For emergency pitching, the drive units are supplied with power from the corresponding energy storage. The rotor blades move automatically and independently of each other into a position in which they do not generate any lift; this is called the feathered position.

Since the 3 pitch units are interconnected but also operate independently of each other, if one component fails, the remaining pitch units can still function and stop the rotor.

Emergency braking

If a person presses an emergency stop button, or if the rotor lock is used while the rotor is turning, the control system initiates an emergency braking procedure.

This means that in addition to the emergency pitching of the rotor blades, the rotor brake is applied. The rotor is decelerated from rated speed to a standstill within 10 to 15 seconds.

7 Remote monitoring

By default, all ENERCON wind energy converters are equipped with the ENERCON SCADA (Supervisory Control And Data Acquisition) system that connects them to Technical Service Dispatch. Technical Service Dispatch can retrieve each wind energy converter's operating data at any time and instantly respond to any irregularities or malfunctions.

The ENERCON SCADA system also transmits all status messages to Technical Service Dispatch, where they are permanently stored. This ensures that the practical experience gained through the long-term operation of ENERCON wind energy converters is taken into account for their continued development.

Connection of the individual wind energy converters is through a dedicated personal computer (ENERCON SCADA Server), which is typically located in the transmission substation or in the associated substation. There is one ENERCON SCADA Server in every wind farm.

The ENERCON SCADA system, its properties and its operation are described in separate documentation.

At the operator/owner's request, monitoring of the wind energy converters can be performed by a third party.

8 Maintenance

In order to ensure optimum and safe long-term operation of the wind energy converter, maintenance is required at regular intervals.

ENERCON wind energy converters are regularly serviced at least once a year, depending on requirements.

During maintenance, all safety-relevant components and features are inspected, e.g. pitch control, yaw control, safety systems, lightning protection system, anchorage points, and safety ladders. The bolt connections are checked on load-bearing joints (main components). All other components are visually inspected to check for any irregularities or damage. Lubrication systems are refilled.

Maintenance intervals may deviate, depending on regional regulations and standards.

Technical Specifications E-141 EP4

General	
Manufacturer	ENERCON GmbH Dreekamp 5 26605 Aurich Germany
Type designation	E-141 EP4
Nominal power	4200 kW
Hub heights	129.05 m, 159 m
Rotor diameter	141 m
IEC wind class (ed. 3)	IIIA
Extreme wind speed at hub height (10-minute mean)	37.5 m/s Corresponds to a load equivalent of approx. 52.5 m/s (3-second gust)
Annual average wind speed at hub height	7.5 m/s

Rotor with pitch control	
Type	Upwind rotor with active pitch control
Rotational direction	Clockwise
Number of rotor blades	3
Rotor blade length	66.7 m (segmented rotor blade)
Swept area	15614.5 m ²
Rotor blade material	GRP/epoxy resin/balsa wood/foam
Lowest power feed speed to nominal speed	4 – 10.4 rpm
Tip speed at speed setpoint	Up to 78.3 m/s
Power reduction wind speed	28 – 34 m/s (with optional ENERCON storm control)
Conical angle	0°
Rotor axis angle	5°
Pitch control	One independent electrical pitch system per rotor blade with dedicated emergency power supply

Drive train with generator	
Wind energy converter concept	Gearless; variable speed; full-scale converter
Hub	rigid
Bearing	Double-row tapered/cylindrical roller bearing
Generator	Direct-drive ENERCON annular generator
Grid feed	ENERCON inverters with high clock speed and sinusoidal current
IP Code/insulation class	IP 23/F

Brake system	
Aerodynamic brake	Three independent pitch systems with emergency power supply
Rotor brake	Electromechanical
Rotor lock	Latching every 5°

Yaw control	
Type	Electrical with yaw motors
Control system	Active via yaw gears

Control system	
Type	Microprocessor
Grid feed	ENERCON inverter
Remote monitoring system	ENERCON SCADA
Uninterruptible power supply (UPS)	Integrated

Tower variants			
Hub height	Total height	Type	Wind class
129.05m	199.55 m	Hybrid tower	IEC IIIA ¹ DIBt WZ2 GK I+II ²
159 m	229.5 m	Hybrid tower (external prestressing)	IEC IIIA ¹ DIBt WZ2 GK I+II ²

¹Edition 3

²Edition 2012